



CITY

60114




LEGO.com/city



WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.





AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.


Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.



ADVERTENCIA: PELIGRO DE ASFIXIA.

No recomendado para niños menores de 3 años. Contiene piezas pequeñas.


1



2




1





2







1







2





3






4






5




6






1x



7




8




8





9







10









11








12







13






14





2x

15






2x



1x


16





1x


17





2x

18







2x





2x


19







20







21






2x

22





23






1x



1x


24








1x

25






26





1x


27





2x


28





1x


29





2x


30





2x

31







1x



1x


32





2x


33








1x

34






35





1x



36





1x

37







1x



1x


38







1x


39








40





41







CITY



60090



60091



60092



60093



60095

LEGO.COM/CITY



CITY



60079



60080



60078



60077

LEGO.COM/CITY



CITY



60076



60074



60073



60072

LEGO.COM/CITY



CITY



60051



60052



60050

LEGO.COM/CITY



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346